

LOWI AIRAC 1803 (01.Mär.2018)

SID

ADIL0	(*)	RTT (Rattenberg)	(*)
8	ADIL02J ATC	8	RTT3J ATC
26	ADIL03H ATC	8	RTT2Q ATC
		26	RTT4H ATC
		26	RTT1R ATC
		26	RTT3X ATC
BRENO		UNKEN	
8	BRENO2J ATC	8	UNKEN2J ATC
26	BRENO3H ATC	26	UNKEN3H ATC
KOGOL			
8	KOGOL3J ATC		
26	KOGOL4H ATC		
KPT (Kempten)			
8	KPT5J ATC		
MOGTI			
26	MOGT13H ATC		
26	MOGT11X ATC		
OBEDI			
8	OBEDI3J ATC		
26	OBEDI4H ATC		

Fettgedruckt = RNAV

(*) Initial climb by ATC. On IVAO, initial climb by default FL120.



STAR

SGB3A	9500	
NANIT1A	15000	
TULSI3A	9500	RTT 9500
BRENO2A	14000	
BRENO3B	14000	
MADEB1B	13000	ELMEM 13000
RTT1B	13000	
XEBIX1B	13000	

LOC/DME Frequencies:

LOC/DME East	OEV	111.10	255°	9500
LOC R 26	RTT	303		
LOC/DME West	OEJ	109.70	066°	13000

Holdings

Waypoint	CRS	Turn	MHA
RTT	226°	RT	9500
ELMEM	149°	LT	13000

VFR Entry / Exit Points

Meldepunkt	Richtung
Mike 3	E
Mike 2	E
Mike 1	E
India	W
Whiskey 1	W
November 2	NW
November 1	NW
Sierra	S
Brenner	S

ATC-Positionen

LOWI_DEL	121.800	*
LOWI_TWR	120.100	
LOWI_APP	119.275	
LOWI_U_APP	132.450	*
LOVV_S_CTR	133.800	
LOVV_(N)_CTR	134.350	

* Nur mit Genehmigung AT-HQ

Anmerkungen

- D(CTR) Innsbruck: 7000ft MSL
 -Transition Altitude:
 für Departures grundsätzlich 10.000ft,
 in der Nähe der MRVAs aber immer
 Altitude verwenden!
 (Ggf. auch für Outbounds)

Squawks

Range	Purpose
0001 - 0017	local (VFR)
0301 - 0377	BI EG EI Transatlantic
3401 - 3477	
1330 - 1357	LO LI LM LE LF via LI
1500 - 1577	FIS LO secondary
1572	Polizei
1657	Rescue
1740 - 1777	EK EN ES
5001 - 5077	Military
5140 - 5167	EE EF EP EV ES EY LB LH LK
	LR LU LZ U
1740 - 1777	EB ED EH EL LF LE LP LS
6110 - 6177	
7301 - 7377	
7101 - 7177	BK LA LB LC LD LG LJ LQ
	LT LW LY HLT LW LY H OM
2001 - 2077	Transit-Flights through Austria